

The Main Teton Tough Differences



Most Advanced Paint Job In The Industry.

Tough Paint:

Epoxy Primer w/Anodes. (Uses Polarized Electricity To Fight The Spread Of Rust)



Tough Tube Frame:

The Difference is Simple.

Steel Square Tube Frames Are Much Stronger Than Channel Frames.

Tough Radial Tires:

No Excuses Guarantee For The 1st Year



